



BELP Series

Ducted Ultima VRF Indoor Unit



Part List Manual

220-240V/1/50-60Hz



Exploded View



Model: BELP006N0A-DCV018



EX_ID	Spare Parts Code	Part Name(EN)	Qty.
1	12226000005414	Chassis Assembly	1
2	12226000005407	Side Panel Assembly	1
3	12126000002545	Drain Pan	1
4	12226000005411	Upper Cover Assembly	1
5	12226000005416	Beam Assembly	1
6	12226000005406	Pipe Clamp Board Assembly	1
7	12100103001066	Centrifugal Fan	2
8	12226000005417	Upper Cover Assembly	1
9	11002015011808	Brushless DC Motor	1
10	12226000005719	Electrical Control Box Cover	1
11	17226000A09454	Electrical Control Box Assembly	1
11.1	11201007004523	Room Temperature Sensor	1
11.2	17122300A03720	Indoor Unit Main Control Board	1
12	17400802003255	Drain Pump Assembly	1
12.1	17400802002994	Drain Pump	1
12.2	12626000000300	Drain Hose Assembly	1
12.3	17400511000029	Water Level Switch	1
13	12126000002370	Volute	2
14	12126000002369	Volute	2
15	15826000004076	Evaporator assembly	1
15.1	11201007000094	Pipe Temperature Sensor	1
15.2	11201007004484	Pipe Temperature Sensor	1
15.3	11201007004483	Pipe Temperature Sensor	1
16	12226000005405	Sealing Plate Assembly	1

Exploded View



Model: BELP007N0A-DCV020



EX_ID	Spare Parts Code	Part Name(EN)	Qty.
1	12226000005414	Chassis Assembly	1
2	12226000005407	Side Panel Assembly	1
3	12126000002545	Drain Pan	1
4	12226000005411	Upper Cover Assembly	1
5	12226000005416	Beam Assembly	1
6	12226000005406	Pipe Clamp Board Assembly	1
7	12100103001066	Centrifugal Fan	2
8	12226000005417	Upper Cover Assembly	1
9	11002015011808	Brushless DC Motor	1
10	12226000005719	Electrical Control Box Cover	1
11	17226000A09454	Electrical Control Box Assembly	1
11.1	11201007004523	Room Temperature Sensor	1
11.2	17122300A03720	Indoor Unit Main Control Board	1
12	17400802003255	Drain Pump Assembly	1
12.1	17400802002994	Drain Pump	1
12.2	12626000000300	Drain Hose Assembly	1
12.3	17400511000029	Water Level Switch	1
13	12126000002370	Volute	2
14	12126000002369	Volute	2
15	15826000004076	Evaporator assembly	1
15.1	11201007000094	Pipe Temperature Sensor	1
15.2	11201007004484	Pipe Temperature Sensor	1
15.3	11201007004483	Pipe Temperature Sensor	1
16	12226000005405	Sealing Plate Assembly	1

Exploded View



Model: BELP008N0A-DCV022



EX_ID	Spare Parts Code	Part Name(EN)	Qty.
1	12226000005414	Chassis Assembly	1
2	12226000005407	Side Panel Assembly	1
3	12126000002545	Drain Pan	1
4	12226000005411	Upper Cover Assembly	1
5	12226000005416	Beam Assembly	1
6	12226000005406	Pipe Clamp Board Assembly	1
7	12100103001066	Centrifugal Fan	2
8	12226000005417	Upper Cover Assembly	1
9	11002015011808	Brushless DC Motor	1
10	12226000005719	Electrical Control Box Cover	1
11	17226000A09454	Electrical Control Box Assembly	1
11.1	11201007004523	Room Temperature Sensor	1
11.2	17122300A03720	Indoor Unit Main Control Board	1
12	17400802003255	Drain Pump Assembly	1
12.1	17400802002994	Drain Pump	1
12.2	12626000000300	Drain Hose Assembly	1
12.3	17400511000029	Water Level Switch	1
13	12126000002370	Volute	2
14	12126000002369	Volute	2
15	15826000004076	Evaporator assembly	1
15.1	11201007000094	Pipe Temperature Sensor	1
15.2	11201007004484	Pipe Temperature Sensor	1
15.3	11201007004483	Pipe Temperature Sensor	1
16	12226000005405	Sealing Plate Assembly	1

Exploded View


Model: BELP010N0A-DCV028




EX_ID	Spare Parts Code	Part Name(EN)	Qty.
1	12226000005414	Chassis Assembly	1
2	12226000005407	Side Panel Assembly	1
3	12126000002545	Drain Pan	1
4	12226000005411	Upper Cover Assembly	1
5	12226000005416	Beam Assembly	1
6	12226000005406	Pipe Clamp Board Assembly	1
7	12100103001066	Centrifugal Fan	2
8	12226000005417	Upper Cover Assembly	1
9	11002015011808	Brushless DC Motor	1
10	12226000005719	Electrical Control Box Cover	1
11	17226000A09454	Electrical Control Box Assembly	1
11.1	11201007004523	Room Temperature Sensor	1
11.2	17122300A03720	Indoor Unit Main Control Board	1
12	17400802003255	Drain Pump Assembly	1
12.1	17400802002994	Drain Pump	1
12.2	12626000000300	Drain Hose Assembly	1
12.3	17400511000029	Water Level Switch	1
13	12126000002370	Volute	2
14	12126000002369	Volute	2
15	15826000004076	Evaporator assembly	1
15.1	11201007000094	Pipe Temperature Sensor	1
15.2	11201007004484	Pipe Temperature Sensor	1
15.3	11201007004483	Pipe Temperature Sensor	1
16	12226000005405	Sealing Plate Assembly	1

Exploded View

Model: BELP012N0A-DCV036




11.3 11.1 11.2 11




EX_ID	Spare Parts Code	Part Name(EN)	Qty.
1	12226000005422	Chassis Assembly	1
2	12226000005407	Side Panel Assembly	1
3	12126000002544	Drain Pan	1
4	12226000005421	Upper Cover Assembly	1
5	12226000005425	Beam Assembly	1
6	12226000005406	Pipe Clamp Board Assembly	1
7	12100103001065	Centrifugal Fan	2
8	12226000005426	Upper Cover Assembly	1
9	11002015011808	Brushless DC Motor	1
10	12226000005719	Electrical Control Box Cover	1
11	17226000A09454	Electrical Control Box Assembly	1
11.1	11201007004523	Room Temperature Sensor	1
11.2	17122300A03720	Indoor Unit Main Control Board	1
12	17400802003255	Drain Pump Assembly	1
12.1	17400802002994	Drain Pump	1
12.2	12626000000300	Drain Hose Assembly	1
12.3	17400511000029	Water Level Switch	1
13	12126000002364	Volute	2
14	12126000002368	Volute	2
15	15826000004072	Evaporator assembly	1
15.1	11201007000094	Pipe Temperature Sensor	1
15.2	11201007004484	Pipe Temperature Sensor	1
15.3	11201007004483	Pipe Temperature Sensor	1
16	12226000005405	Sealing Plate Assembly	1

Exploded View

Model: BELP015N0A-DCV045




11.3 11.1 11.2 11



EX_ID	Spare Parts Code	Part Name(EN)	Qty.
1	12226000005433	Chassis Assembly	1
2	12226000005407	Side Panel Assembly	1
3	12126000002543	Drain Pan	1
4	12226000005435	Upper Cover Assembly	1
5	12226000008180	Beam Assembly	1
6	12226000005406	Pipe Clamp Board Assembly	1
7	12100103001664	Centrifugal Fan	2
8	12226000005436	Upper Cover Assembly	1
9	11002015011809	Brushless DC Motor	1
10	12226000005719	Electrical Control Box Cover	1
11	17226000A09456	Electrical Control Box Assembly	1
11.1	11201007004523	Room Temperature Sensor	1
11.2	17122300A03719	Indoor Unit Main Control Board	1
12	17400802003255	Drain Pump Assembly	1
12.1	17400802002994	Drain Pump	1
12.2	12626000000300	Drain Hose Assembly	1
12.3	17400511000029	Water Level Switch	1
13	12126000002364	Volute	2
14	12126000002368	Volute	2
15	15826000003579	Evaporator Assembly	1
15.1	11201007000094	Pipe Temperature Sensor	1
15.2	11201007004484	Pipe Temperature Sensor	1
15.3	11201007004483	Pipe Temperature Sensor	1
15.4	15426000002700	Evaporator Inlet Pipe Assembly	1
15.4.1	15426000002398	Electronic Expansion Valve Assembly	1
15.4.1.1	15500213002734	Electronic Expansion Valve Suite	1
16	12226000005405	Sealing Plate Assembly	1

Exploded View

Model: BELP019N0A-DCV056




11.3

11.1

11.2



11



EX_ID	Spare Parts Code	Part Name(EN)	Qty.
1	12226000005433	Chassis Assembly	1
2	12226000005407	Side Panel Assembly	1
3	12126000002543	Drain Pan	1
4	12226000005435	Upper Cover Assembly	1
5	12226000008180	Beam Assembly	1
6	12226000005406	Pipe Clamp Board Assembly	1
7	12100103001664	Centrifugal Fan	2
8	12226000005436	Upper Cover Assembly	1
9	11002015011809	Brushless DC Motor	1
10	12226000005719	Electrical Control Box Cover	1
11	17226000A09455	Electrical Control Box Assembly	1
11.1	11201007004523	Room Temperature Sensor	1
11.2	17122300A03718	Indoor Unit Main Control Board	1
12	17400802003255	Drain Pump Assembly	1
12.1	17400802002994	Drain Pump	1
12.2	12626000000300	Drain Hose Assembly	1
12.3	17400511000029	Water Level Switch	1
13	12126000002364	Volute	2
14	12126000002368	Volute	2
15	15826000003579	Evaporator Assembly	1
15.1	11201007000094	Pipe Temperature Sensor	1
15.2	11201007004484	Pipe Temperature Sensor	1
15.3	11201007004483	Pipe Temperature Sensor	1
15.4	15426000002700	Evaporator Inlet Pipe Assembly	1
15.4.1	15426000002398	Electronic Expansion Valve Assembly	1
15.4.1.1	15500213002734	Electronic Expansion Valve Suite	1
16	12226000005405	Sealing Plate Assembly	1

Exploded View

Model: BELP024N0A-DCV071



EX_ID	Spare Parts Code	Part Name(EN)	Qty.
1	12226000005401	Chassis Assembly	1
2	12226000005959	Side Panel Assembly	1
3	12122000007617	Bearing Ball	1
4	12600901000660	Bearing Block	1
5	12226000005445	Support Plate	1
6	12126000002546	Drain Pan	1
7	12226000005399	Upper Cover Assembly	1
8	12900601000246	Connecting Shaft	1
9	12126000002364	Volute	3
10	12126000002368	Volute	3
11	12100103001664	Centrifugal Fan	3
12	12226000005408	Upper Cover Assembly	1
13	12600401000652	Rubber Pad	1
14	12918000001320	Coupling	1
15	11002015019574	Brushless DC Motor	1
16	12226000005719	Electrical Control Box Cover	1
17	17226000A09455	Electrical Control Box Assembly	1
17.1	11201007004523	Room Temperature Sensor	1
17.2	17122300A03718	Indoor Unit Main Control Board	1
17.3	12226000007040	Electrical Control Box Sheet Metal Assembly	1
18	12226000008179	Beam Assembly	1
19	17400802003255	Drain Pump Assembly	1
19.1	17400802002994	Drain Pump	1
19.2	12626000000300	Drain Hose Assembly	1
19.3	17400511000029	Water Level Switch	1
20	12226000005406	Pipe Clamp Board Assembly	1
21	12226000005405	Sealing Plate Assembly	1
22	15826000003576	Evaporator Assembly	1
22.1	11201007000094	Pipe Temperature Sensor	1
22.2	11201007004483	Pipe Temperature Sensor	1
22.3	11201007004484	Pipe Temperature Sensor	1
22.4	15426000002701	Evaporator Inlet Pipe Assembly	1
22.4.1	15426000002404	Electronic Expansion Valve Assembly	1
22.4.1.1	15500213002734	Electronic Expansion Valve Suite	1